

ZIP Varipoint III

Direct unvented water heaters

Models: VP303, VP503, VP803, VP953



Contents

General Product Description	3
Approvals	3
Technical Data	4
Dimensions	4
Safety Information	5
WARNINGS ⚠	5
CAUTIONS ⚡	6
Spare Parts	7
Components supplied with the unit for site fitting	7
Installation	8
Pipe fitting diagram	8
Requirements	9
Discharge	10-11
Positioning	12
Plumbing	12
Electrical	13
Commissioning & Operation	14
Inspection schedule	14
Maintenance	15
Draining	15
De-installation	15
Fault Finding	16
Warranty	17

Installation must only be undertaken by a competent person holding a current Registered Operative Identity card for the installation of unvented domestic hot water storage systems issued by an accredited body.

Please leave these instructions with the end user after installation.

Description

These instructions will guide you through the installation, maintenance and use of the Zip Varipoint III, however, if you require any further information please call Zip customer service on 0845 6 005 005 or 0345 6 005 005.

- The Zip Varipoint III is an unvented water heater designed for connection directly to incoming mains water supply and can serve one or more outlets using conventional taps.
- Care should be taken that the unit being chosen can meet the demands of the outlets being supplied.
- The casing is constructed of powder coated steel and heat losses are minimised by the high efficiency CFC free polyurethane foam insulation.
- The inner vessel is constructed from heavy guage copper and pressure tested to 1.2 MPa (12 bar).
- A manually resettable safety cut out automatically cuts off the electrical supply to the heating element in the event of a malfunction.

If the hot water system is not used for two weeks or more, it is recommended that a hot tap be turned on for several minutes at a sink, basin or bath, it is not recommended that either a dishwasher, clothes washer or other appliance be used before the heater is returned to service.

The Zip Varipoint III must be installed in accordance with these instructions and all current legislation, codes of practice and regulations governing the installation of unvented hot water cylinders in force at the time of installation.

To ensure you have the latest revision of this instruction manual, please visit www.zipheaters.co.uk to download the latest copy.

Please contact Zip Customer Service for advice on 0845 6 005 005 or 0345 6 005 005

Approvals

Zip Varipoint III complies with LVD and EMC directives and is CE endorsed.

Zip Varipoint III has been examined, tested and found, when correctly fitted, to comply with the requirements of the United Kingdom Water Regulations/Byelaws (Scotland). The product, therefore, is listed under the WRAS (Water Regulations Advisory Scheme) Water Fitting and Materials Directory.

Technical data

Model	Zip Varipoint III				
		VP303	VP503	VP803	VP953
Declared load profile		S	M	L	L
Energy efficiency class ⁽¹⁾		C	C	C	C
Energy efficiency (η_{wh}) ⁽¹⁾	[%]	32.5	36.6	37.3	37.3
Annual electricity consumption ⁽¹⁾	[kWh]	568	1,401	2,748	2,746
Thermostat temperature setting		55°C	55°C	65°C	60°C
Specific precautions	See installation and operating instructions				
“Smart” value		0			
Rated volume	[l]	30.0	50.0	80.0	100.0
Mixed water at 40°C (V_{40}) ⁽²⁾	[l]	-	76.0	132.0	148.0
Weight empty / full	[kg]	16.0 / 49.0	20.0 / 71.5	27.0 / 109.0	33.0 / 134.0
Power rating	[W]	2,755			
Nominal supply voltage	[V]	230			
Protection class		IP24			
Heat up time (10°C to 65°C)	[mins]	46	72	115	141
Maximum working pressure	[MPa]	0.55			
Water connections		1/2" BSP			

(1) EU Regulation 812/2013; EN 50440

(2) EN 50440

Controls: Pressure reducing valve and line strainer set to 0.35 MPa (3.5 bar)

Expansion relief and single check valve set to 0.6 MPa (6 bar)


Pressure and temperature relief valve set to 0.7 MPa (7 bar) and 90°C

Expansion vessel pre-charged to 0.35 MPa (3.5 bar)


Expansion vessel capacity: 5 litre - VP303, VP503

8 litre - VP803, VP953

All dimensions (mm)





	A (mm)	B (mm)	C (mm)	D (mm)
VP303	376	460	430	448
VP503	564	648	430	448
VP803	705	786	485	503
VP953	850	931	485	503



IMPORTANT:

PLEASE READ THESE INSTRUCTIONS CAREFULLY.

NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE USE.

WARNING: 	Indicates a potentially hazardous situation, which, if not avoided, could result in death and/or serious injury and/or property damage.
CAUTION: 	Indicates a potentially hazardous situation, which, if not avoided, may result in property damage.

Safety Information

WARNINGS

- **Installation, commissioning and maintenance of this appliance must only be carried out by a competent installer, familiar with unvented systems who will then be responsible for adhering to all relevant standards and regulations.**
- The appliance must be permanently connected to the supply through an isolating switch with a contact separation of at least 3mm in all poles.
- To protect the appliance, a circuit breaker must be fitted with a rating suitable for the nominal current of the appliance.
- The cross sectional area of the connection cable must be appropriate for the power rating and location of the appliance.
- The connecting cable must be adequately secured.
- This appliance must be earthed at all times.
- Check that the power supply is switched off prior to electrical connection.
- The appliance, its wiring and piping must not be modified in any way.
- Do not remove the electrical cover panel whilst the unit is connected to the electrical supply.
- In case of malfunction isolate the power supply immediately. In case of leaks also isolate the water supply. Repairs must only be carried out by Zip Heaters (UK) Ltd or an authorised Zip service engineer.
- Do not reset the over temperature cut-out until the cause of its operation has been diagnosed and necessary repairs have been undertaken.
- Do not use the water heater if it is suspected of being frozen. Switch off the electrical supply if water ceases to flow and do not switch on again until a competent person has checked that it is safe to do so.

- The heater should be visually inspected regularly. This is particularly important if the heater is located in a cupboard, roof space or any other concealed location. If there is any sign of leaks or seepage the heater should be isolated from the water supply and switched off from the electrical supply until a competent person has investigated the cause.
- Do not block or restrict the discharge from any safety valve.
- Do not tamper with any safety valve.
- The appliance must not be subjected to pressure exceeding 0.55 MPa (5.5 bar).
- If water discharges from any safety valve switch off the electrical supply to the unit, isolate the water supply and contact a competent person familiar with unvented systems.
- Temperatures in excess of approximately 43°C are perceived as hot, especially by children, and may cause a feeling of burning.
- This appliance must not be used by any person (including children) with limited physical, sensorial or mental abilities or failing experience and/or knowledge unless they are supervised by a person responsible for their safety or received instructions about how to use the appliance.
- Children should be supervised in order to make sure that they do not play with the appliance.

CAUTIONS

- The appliance must only be used when correctly installed and in perfect working order.
- The appliance must be installed in a frost-free room and must never be exposed to frost.
- The Zip Varipoint range is not recommended for use with secondary circulation systems.
- The appliance must be completely filled with water before being switched on.
- The appliance must only be used for heating potable water. The appliance must not be used for any other purpose.
- When the appliance has been in use for some time, the fittings may be very hot.
- The Zip Varipoint is intended for connection to mains supply only. In any other case please contact Zip on 0845 6 005 005 or 0345 6 005 005 for advice.
- **Zip Heaters (UK) Ltd cannot be held liable for any damages caused by failure to observe these instructions.**

Spare Parts

Part No.	Description
VP0330	Element, plate & gasket
VP0331	Gasket
VP0332	Resettable cut-out
VP0333	Thermostat
VP0334	Neon indicator
AQ0317	Temperature & pressure relief valve

Components supplied with the unit for site fitting

- Cold Inlet assembly comprising pressure reducing valve with integral line strainer and expansion relief valve with check valve, expansion vessel take off and balanced cold water take off. (See Fig.1)
- Expansion vessel and wall fixing bracket.
- Zip Varipoint hot water cylinder wall locating bracket.
- Tundish.
- Tee Piece & drain valve.





Fig.1 Cold Inlet Set - Connections




The Zip Varipoint III hot water cylinder will be delivered in its carton with the various control valves and fittings supplied in a separate carton. Both should be left packed until needed.

Factory Fitted Components

- Heating elements.
- Thermostats with over temperature cut-outs.
- Temperature and pressure relief valve.

Pipe fitting diagram



Warning!

Do Not Fit Isolation (Shut Off) Valve Between Cylinder and Expansion Valve.

1	Cold Main
2	Balanced Cold Connection
3	Expansion Vessel with Wall Bracket, from 'cold inlet set' take off
4	Hot Water Outlet
5	Temperature Control
6	Neon Indicator
7	Tundish To Drain
8	Temperature and Pressure Relief Valve
9	Expansion Relief Valve To Drain Via Tundish
10	Check Valve
11	Pressure Reducing Valve
12	Isolating Valve (not supplied)
13	Tee Piece and Drain Valve

Installation

Requirements

Prior to installation the Zip Varipoint III should be kept upright in its original packaging and handled with care always lifting from underneath.

The Zip Varipoint III should be stored in a covered, dry area protected at all times from the weather.

These instructions must be read and fully understood before commencing the installation. If in doubt, or in need of further guidance please ring Zip on 0845 6 005 005 or 0345 6 005 005.

Installation must only be undertaken by a competent person holding a current Registered Operative Identity card for the installation of unvented domestic hot water storage systems issued by an accredited body.

The Zip Varipoint III must be installed in accordance with these instructions and all current legislation, codes of practice and regulations governing the installation of unvented hot water cylinders in force at the time of installation.

All connections should be made to the Zip Varipoint III and its safety devices using the 15mm or 22mm compression fittings, nuts and olives supplied.

The electrical installation including earthing and cross bonding must comply with the current IEE regulations and any Local Authority requirements.

The cold water inlet set assembly comprises a pressure reducing valve with integral strainer, expansion relief, check valve and expansion vessel. All of these components must be included in the installation. The pressure settings on these components are factory set and indicated on the top of the valve. Do not break any seals or attempt to adjust any safety valve; to do so may impair the safety of the installation and will invalidate the warranty.

It is recommended that the unit is installed according to these instructions.

Under no circumstances should the expansion relief valve be installed in an inverted position as fouling of the seat caused by deposits may prevent it from operating correctly.

Safety relief valve connections should not be used for any other purpose and no valve should be fitted between the expansion relief valve and the storage cylinder.

An isolating valve must be fitted to the cold water supply to the inlet manifold.

The Zip Varipoint III is designed for use with a supply pressure up to 1.2 MPa (12 bar). For supply pressures exceeding 1.2 MPa (12 bar) an additional pressure reducing valve must be fitted in the cold water supply to the unit.

Secondary Circulation

The Zip Varipoint III is not recommended for use with secondary circulation systems.

Discharge

Discharge arrangement

The expansion relief, temperature and pressure relief valves should drain via a tundish which should be installed in a visible location and away from any electrical devices.


The discharge pipe from the tundish should terminate in a safe place where there is no risk to persons in the vicinity of the discharge, be of metal and:

- a) Be at least one pipe size larger than the nominal outlet size of the safety device unless its total equivalent hydraulic resistance exceeds that of a straight pipe 9m long. Discharge pipes between 9m and 18m equivalent resistance length should be at least 2 sizes larger than the nominal outlet size of the safety device, between 18 and 27m at least 3 sizes larger, and so on. Bends must be taken into account in calculating the flow resistance. See diagram of typical discharge pipe arrangement and table for sizing copper discharge pipe on page 11.
- b) Have a vertical section of pipe at least 300mm long, below the tundish before any elbows or bends in the pipework.
- c) Be installed with a continuous fall.
- d) Have discharges visible at both the tundish and the final point of discharge but where this is not possible or it is practically difficult there should be clear visibility at one or other of these locations. Examples of acceptable discharge arrangements are:
 1. Ideally below a fixed grating and above the water seal in a trapped gully.
 2. Downward discharges at a low level: i.e. up to 100mm above external surfaces such as car parks, hard standings, grassed areas etc. are acceptable providing that where children may play or otherwise come into contact with discharges, a wire cage or similar guard is positioned to prevent contact, whilst maintaining visibility.
 3. Discharges at high level: e.g. into metal hopper and metal down-pipe with the end of the discharge pipe clearly visible (tundish visible or not) or onto a roof capable of withstanding high temperature discharges of water and 3m from any plastic guttering system that would collect such discharges (tundish visible).
 4. Where a single pipe serves a number of discharges, such as in blocks of flats, the number served should be limited to not more than 6 systems so that any installation can be traced reasonably easily. The single common discharge pipe should be at least one pipe size larger than the largest individual discharge pipe to be connected. If unvented hot water storage systems are installed where discharges from safety devices may not be apparent e.g. in dwellings occupied by blind, infirm or disabled people, consideration should be given to the installation of an electronically operated device to warn when discharge takes place.

Note: The discharge will consist of scalding water and steam. Asphalt, roofing felt and non-metallic rainwater goods may be damaged by such discharges.

Note: It is not acceptable to discharge straight into a soil pipe. For guidance See G3 3.60

Diagram of a typical discharge pipe arrangement



Valve outlet size	Minimum size of discharge pipe D1	Minimum size of discharge pipe D2 from tundish	Maximum resistance allowed, expressed as a length of straight pipe (i.e. no elbows or bends)	Resistance created by each elbow or bend
G1/2	15mm	22mm	up to 9m	0.8m
		28mm	up to 18m	1.0m
		35mm	up to 27m	1.4m
G3/4	22mm	28mm	up to 9m	1.0m
		35mm	up to 18m	1.4m
		42mm	up to 27m	1.7m
G1	28mm	35mm	up to 9m	1.4m
		42mm	up to 18m	1.7m
		54mm	up to 27m	2.3m

Note! The above chart is based on copper tube.

Plastic pipes may be of a different bore and resistance. Sizes and maximum lengths of plastic should be calculated using data prepared for the type of pipe being used.

Positioning

The Zip Varipoint should be installed vertically with the electrical cover panel and water connections underneath.

The unit is designed to be wall mounted using the wall fixings supplied with the product. Ensure that the wall where the unit is to be located is sufficiently strong to support the full weight of the unit (see dimensions) and capable of accepting suitable fixings.

Position the Zip Varipoint III to allow for provision of the cold water supply, discharge fittings and pipework as well as access for future maintenance, repair of the unit or its replacement.

Reasonable clearance will be required to give access to pressure controls, element assembly, draining facility, pipe connections and expansion vessel.

A gap of 250mm should be left between the top of the unit and the ceiling. A gap of 400mm should be left between the bottom of the unit and any floor or work surface.

Do not install in a location where the unit or connecting pipework can freeze.

Fix the Zip Varipoint III hot water cylinder locating bracket to the wall with suitable fixings as shown in the diagram and table of dimensions on page 3.

Position the Zip Varipoint III securely on the locating bracket.

The expansion vessel should be securely fitted to a suitable and convenient wall using the fittings supplied and positioned to enable its connection to the cold inlet set.

When deciding the final location of the heater consideration should be given to the safe and visible disposal of any water resulting from leaks or seepage.

This is particularly relevant when the heater is located in a roof space, cupboard or any concealed location.

For guidance please ring Zip Heaters on 0845 6 005 005 or 0345 6 005 005

Plumbing

1. The unit should be provided with a continuous cold water supply via 22mm pipework.
2. The water connections are at the bottom of the appliance and suitable for either 15mm compression or 1/2" BSP fittings.
When viewed from the front, the cold feed connection is to the right the hot outlet from the heater is to the left.
3. The Tee piece and drain valve supplied should be installed on the cold feed to the heater to enable it to be drained down for servicing or replacement.
4. An isolating valve (not supplied) should be fitted in the cold water supply pipework to the inlet manifold assembly to enable isolation of the water supply to the unit for servicing or replacement.
5. Fit the inlet manifold assembly to the 22mm supply pipework with the valve caps facing upwards and in the correct direction of flow as indicated by the arrows.
6. The pressure gauge connection point on the cold inlet set assembly should be accessible or connection of a pressure gauge if necessary.

7. Provide suitable drainage from the Expansion relief and Temperature & Pressure Relief Valves via the tundish using 15mm copper tube. Refer to installation requirements.
8. Connect the expansion vessel to the cold inlet set assembly take off (see page 6).
9. A balanced mains pressure cold water supply for a shower may be provided from the connection provided on the cold inlet set, otherwise this should be blanked.

Note: This connection should not be used to supply cold taps.

10. Flush all pipe work thoroughly before making the final connections from the cold supply to the manifold assembly to ensure that any debris is removed. Failure to do this may result in irreparable damage to the controls and will invalidate the warranty.
11. Connect the hot water supply pipe to the outlet from the heater.
12. Connect the discharge pipe from the tundish. Refer to Installation Requirements.

Electrical

Switch off the mains electrical supply before removing the electrical cover panel or carrying out any work involving a live circuit or access to components that may be live.

Do not switch on the electrical supply until the unit is full of water.

This appliance must be earthed.

The electrical connection to the heating elements must conform to current IEE wiring regulations and be permanently connected to the electrical supply through a double-pole isolating switch with at least 3mm contact separation in each pole and with a minimum rating of 13A.

All internal wiring is factory mounted and should not be altered or modified.

After removing the electrical cover panel, a suitable supply cable should be fed through the clamp on the underside of the appliance, connected to the live and neutral connections on the terminal block and earth terminal on the element plate before securing with the cable clamp.

Check all electrical connections for security and tightness before replacing the cover.

The appliance has a working thermostat adjustable between 37°C and 75°C.

An over temperature cut-out is incorporated within the thermostat which is designed to operate at 79-84°C. Should this happen, press the reset button.

Important: Before resetting the over temperature cut-out or altering the thermostat setting, isolate the electrical supply to the unit before removing the electrical cover panel. Ensure that the cover panel is replaced correctly and the retaining screws fitted before re-connecting the electrical supply.

Commissioning

1. Check that all the requirements under “Installation Requirements” have been met.
2. Check that all water and electrical connections are correct and tight.
3. Check that the expansion vessel pressure is correct – refer to label on vessel for correct pressure.
4. Check that the drain valve is closed.
5. Open hot water taps.
6. Open the cold water supply valve and permit the heater to fill.
7. Leave hot taps open until all air has been purged from the system and water is flowing freely from all outlets.
8. Check for leaks and rectify as necessary.
9. Check the operation of both the T&P relief valve and the Expansion Relief Valve to ensure free water flow through the discharge pipe by turning the knob to the left and holding in the open position.
10. Adjust the temperature control to the desired setting as required.
11. Switch on the electrical supply to the unit. The pilot light will illuminate to indicate that the elements are operating.
12. During the heating cycle no water should escape to waste from either the expansion relief or T&P relief valves.
13. Allow the heater to reach the selected temperature when the pilot light will extinguish. Check the water temperature and re-check water connections adjusting as necessary.
14. Pass these instructions to the person responsible for the building management.

Inspection schedule

It is recommended that all key components of the heater should be inspected on a regular basis, no greater than twelve monthly intervals, for continued safe and efficient operation. The inspection should be carried out by a competent person familiar with unvented systems and the components to be inspected should include the following:

1. Expansion relief valve. Check for correct operation.
2. T&P relief valve. Check for correct operation.
3. Check expansion vessel pressure – refer to label on vessel for correct pressure.
4. Inspect integral line strainer and clean as necessary.
5. Check that the discharge pipework is free of any obstructions.
6. Check that all electrical connections are tight.

Maintenance

1. The Zip Varipoint III is an unvented electric water heater and a competent person, familiar with unvented systems, should carry out all servicing and maintenance.
2. Do not remove the electrical cover panel whilst the unit is connected to the electrical supply.
3. Do not reset the over temperature cut-out until the cause of its operation has been diagnosed and necessary repairs have been undertaken.
4. Do not use the water heater if it is suspected of being frozen. Switch off the electrical supply if water ceases to flow and do not switch on again until a competent person has checked that it is safe to do so.
5. The heater should be visually inspected regularly. This is particularly important if the heater is located in a cupboard, roof space or any other concealed location. If there is any sign of leaks or seepage the heater should be isolated from the water supply and switched off from the electrical supply until a competent person has investigated the cause.
6. Do not block or restrict the discharge from any safety valve.
7. Do not tamper with any safety valve.
8. If water discharges from any safety valve switch off the electrical supply to the unit, isolate the water supply and contact a competent person familiar with unvented systems.
9. Please note that lime-scale deposits form more readily at higher temperatures. Damage or failures caused by the formation of lime-scale are specifically excluded under the terms of the warranty. To reduce lime-scale formation to a minimum the unit should always be operated at the lowest convenient temperature.
10. If power has been disconnected it is recommended that the unit is drained (see draining).

Draining

To drain the unit:

1. Isolate the electrical supply.
2. Isolate the mains cold water supply to the unit.
3. Open a hot water tap.
4. Connect a suitable hose to the drain point to allow the contents to be drained safely.
5. Open the drain valve and allow the unit to drain.

De-Installation

To de-install the heater:

1. Switch off and disconnect the electrical supply.
2. Close the mains water supply isolating valve.
3. Drain the heater as described in “Draining”.
4. Disconnect the cold water inlet connection from the manifold assembly.
5. Disconnect the hot water supply pipe from the heater outlet.
6. Remove the heater.

Fault Finding

Note: All servicing and repairs must be undertaken by a competent person, familiar with unvented systems.

Fault	Possible Cause	Solution
Over temperature cut-out operates.	<p>The thermostat has failed.</p> <p>The thermostat is set at too high a temperature.</p>	Reset. If the cut-out operates again isolate the unit and contact the installer. Note: Isolate the electrical supply before removing the electrical cover panel and ensure that the panel is correctly replaced and secured before reconnecting.
Regular, intermittent water discharge from tundish.	Loss of pressure from the expansion vessel.	Isolate the heating system and the mains cold water supply. Partly drain the unit. Recharge the expansion vessel to the specified pressure and re-commission.
Regular, intermittent water discharge from tundish.	Thermostat failure.	Isolate the heating system and check thermal controls when discharge ceases. Replace thermostat if faulty.
Continuous water discharge from the tundish.	Pressure reducing valve not operating correctly.	Check with pressure gauge and replace as necessary.
	P&T relief valve not operating correctly.	Check and replace if faulty.
	Expansion relief valve not operating correctly.	Check and replace if faulty.
No water flow from hot taps.	Cold water mains supply isolated.	Restore mains supply to the heater.
	Integral line strainer in pressure reducing valve has become blocked.	Check and clean as necessary.
	Pressure reducing valve incorrectly fitted.	Refit correctly with arrows in direction of flow.
Water from hot taps is cold.	Power supply not switched on.	Check and switch on.
	Over temperature cut-out has operated.	See fault "Over temperature cut-out operates" above.
	Faulty element.	Check and replace as necessary.
	Thermostat failure.	Check and replace as necessary.

Warranty

The Zip appliance you have chosen is precision-built from the finest materials available and should give many years of trouble free service.

Certain warranties may be implied by law into your contract with Zip.

The warranty provided below is additional to these implied warranties and nothing set out below shall limit your statutory rights or rights at law.

Zip Heaters (UK) Ltd warrants that, should the cylinder fail within five(5) years or any component fail within two(2) years of installation, that part will be repaired or replaced free of charge by Zip or its Distributor or Service Provider, except as set out below, provided the appliance is installed and used strictly in accordance with the instructions supplied, and that failure is not due to accident, misuse, abuse, unsuitable water conditions, or to any alteration, modification or repair by any party not expressly nominated by Zip.

No costs are payable by the customer other than any mileage or travelling-time charges incurred by a Zip Service Provider or the cost of removal, cartage and re-installation of any component of the appliance if it needs to be returned for repair to Zip or its Distributor.

This warranty does not cover damage resulting from non-operation of the appliance or consequential damage to any other goods, furnishings or property.

Zip does not exclude, restrict or modify any liability that cannot be excluded, restricted or modified or which cannot, except to a limited extent, be excluded, restricted or modified as between the owner or user and Zip under the laws applicable.

Furthermore, this warranty does not displace any statutory warranty, but, to the extent to which Zip is entitled to do so, the liability of Zip under any statutory warranty will be limited at Zip's option to the replacement of the appliance or supply of equivalent appliance, the payment of the cost of replacing the appliance or acquiring an equivalent appliance, or the payment of the cost of having the appliance repaired or the repair of the appliance.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

To ensure you have the latest revision of this instruction manual, please visit www.zipheaters.co.uk to download the latest copy.

IMPORTANT: No liability is accepted for incorrect use of this product.



The use of this crossed out wheeled bin logo indicates that this product needs to be disposed of separately to any other household waste.

Within each of the European Union member countries, provisions have been made for the collection and recycling of unwanted electrical and electronic equipment.



In order to preserve our environment we ask that you dispose of this product correctly. Please contact Zip Customer Service for advice on 0845 6 005 005 or 0345 6 005 005.



The terms 'Zip' and 'Varipoint' are
registered trademarks

Zip Heaters (UK) Ltd
14 Bertie Ward Way
Dereham
Norfolk
NR19 1TE

Telephone: 0845 6 005 005
Mobile: 0345 6 005 005
Fax: 01362 692448
Web: www.zipheaters.co.uk

